



User Manual for WAFS - 105
Thermal Mass Flow Sensor

Compressed Air Energy Saving Solutions

Smart Measurement Technology That You Can Trust



For More Info
SCAN HERE

About Us

At WiseAir Technologies, our mission is to empower industries with innovative and advanced measurement solutions for compressed air and gases. With over 20 years of expertise in the field of compressed air management, we have developed smart, reliable, and state-of-the-art products that are both accurate and easy to use. Our focus is on incorporating cutting-edge technologies like M2M communication and the Industrial Internet of Things (IIoT) to bring increased automation, improved communication, and self-monitoring to industrial processes.

Our WA range of smart IIoT sensors can be easily integrated into existing manufacturing and energy management software to enhance data collection, exchange, and analysis for improved productivity and efficiency.

Our Network

Our Smart Sensors are Developed with Design and Technology Support from Our Partners Across North America, Europe and Asia. With Our Strong Network of Partners, we offer Seamless and Best-in-Class Service to Our Customers.



Artificial Intelligence and Machine Learning Software

Our software are programmed to analysis and self Diagnose the Measured Datas



Smart IIoT Sensors

For measurement of Flow, Power, Dew Point and Pressure



Product Experts

Product Specialists with Decades of Experience in Compressed Air Measurement and Management

Simplify Your Compressed Air Management With Our Smart Technology

Compressed Air Systems are Dynamic and Highly In-Efficient. Hence they Require Continuous Monitoring for Sustained Benefits. With Our WiseAir 4.0 Smart Sensors and M2M / AI Softwares Your Compressed Air System is Measured, Analysed and Improved Over Time.

With Our Seamless and Detailed Analytical Reports You Can Keep Track Of Your Compressed Air Systems Efficiency with Minimal Human Intervention.

Our Services

We Offer Free Assessment Services to Identify the HotSpots For Improvements and Develop Road Maps for Sustainable Results. Our Product Specialists Can Also Offer You Customised Plans for Monitoring the Key Performance Factors Of Your Compressed Air System.

Connect with Our Expert Product Specialists to Learn How Your Factory Can Begin to Realize Energy and Cost Savings with Our Advanced Solutions.

Call Us

Asia : **+91 90477 78715**
Europe : **+45 36 99 04 22**

Email Us

Asia : **info@wiseair.asia**
Europe : **info@wiseair.asia**

Understand The True Costs Of Compressed Air

In a Compressor's Life Cycle More than 80 % of its Operating Costs is Spent Towards its Energy. Hence Monitoring and Managing Compressors at their Peak Energy Efficiency will give Significant Energy Savings.


Our Smart Sensors Can Provide Vital Informations Like Flow, Power, Dew Point and Pressure. When Our Sensors are Networked with Our AI Software Programs, All the Measured Datas are Analysed and Reported To You With Suggested Action Plans in Real Time.

Manage Your Compressed Air System Efficiently and Effortlessly With Our WiseAir Smart Sensors and AI Softwares.


Energy Costs



Capital Costs



Maintenance Costs



Index

| | |
|-----------------------------------------------------|----|
| 1_ General Information | 4 |
| 2_ About WAFS - 105 Thermal Mass Flow Sensor | 5 |
| 3_ What's in the Box? | 6 |
| 4_ Product Specifications | 7 |
| 5_ Installation - Mechanical | 8 |
| 6_ Installation - Electrical (Wiring) | 8 |
| 7_ Communication Settings | 9 |
| 8_ Warranty | 10 |
| 9_ Calibration | 10 |
| 10_ Need Help | 10 |
| 11_ Technical Support | 10 |
| 12_ Commissioning Report | 14 |

General Information

Please read this user manual in full and carefully observe the notes and instructions before and during installation, operation and maintenance. The manufacturer cannot be held liable for any damage which occurs as a result of non-observance or noncompliance with this user manual.

Should the device be tampered with in any manner other than a procedure which is described and specified in this manual, the warranty is cancelled and the manufacturer is exempt from liability. The device is designed exclusively for the described application.

This user manual should be read carefully by the technician / qualified personnel and the end user. Once you install, use or maintain this product, you accept that you have read, understood and complied with this manual. This manual should be kept with the Flow Meter and made available to relevant personnel as needed. WiseAir Endeavours to make changes to the content of this Manual, and tries to ensure Correctness and well stated, but is not responsible for Omissions or errors and the consequences caused thereby.

● Compressed Air Safety

- Any contact with quickly escaping air or bursting parts of the compressed air system can lead to serious injuries or even death.
- Do not exceed the maximum permitted pressure
- Only use pressure tight installation material.
- Avoid getting hit by escaping air or bursting parts.
- The system must be pressure-less during maintenance work.

● Installing the Flow Meter, Calibration & Maintenance

- The product must be installed properly and frequently calibrated, otherwise it may lead to the wrong measurement values, which can lead to wrong results.
- Always Observe the Direction of Flow When installing the Sensor. The
- Direction is Indicated on the Housing.
- Do Not Exceed the Maximum Operation Temperature at the Sensors Tip.
- Avoid Condensation on the Sensor Element as this will affect the accuracy enormously.
- Please observe national regulations before/during installation and operation.
- Do not disassemble the product.
- Always use a spanner to mount the product properly

● Electrical Safety

- Any contact with energized parts of the product, may lead to an electrical shock which can lead to serious injuries or even death. Consider all regulations for electrical installations.
- The system must be disconnected from any power supply during maintenance work.
- Any electrical work on the system is only allowed by authorised qualified personal.

● Using the Flow Meter

- Do not use this product in explosive areas.
- Do not exceed the permitted operating parameters.
- Any operation exceeding these parameters can lead to malfunctions and may lead to damage on the instrument or the system.
- Do not exceed or go below the permitted storage and operation temperature and pressure.
- This product should be maintained and calibrated frequently, at least every 2 years.

● Storage and Transportation

- Make sure that the transportation temperature of the sensor is between -10°C to 60 °C.
- Storage temperature of the sensor is between -10 °C to 50 °C and the humidity is <90%, no condensation.
- Avoid direct UV and solar radiation during storage.

About WAFS -105 Thermal Mass Flow Meter

● Importance of Flow Meters :

Flow meters are very popular for measuring compressed air systems. Depending on where they are installed, flow meters can tell you the compressor output, system consumption, peaks and troughs as well as average usage. When used well, flow monitoring can help keep your system under control and highlight any unusual activity in your system.

Different types of flow meters should be used depending on the specific location and purpose. However, when it comes to compressed air, flow meters such as vortex or orifice plates can create a pressure drop within the system, ultimately leading to increased operating cost of the entire plant. As such, vortex or orifice plate flow meters are not recommended for compressed air.

● Thermal Mass Flow Sensor :

- Thermal mass flow meter measures gas mass flow based on thermal diffusion theory and thermal principle of Newton. It has two RTDs as its sensor. One RTD is heated to T1 by a heating power rate of P, the other is not heated but to measure the medium temperature T2. So there is a temperature difference $TD = T1 - T2$. TD reach max when mass flow is 0. When the mass flow Q increases, the heat on T1 is taken away so the T1 decline and the TD become smaller. So there is a certain relationship between heating power rate P, difference of temperature TD and mass flow Q as below.

$$P/TD = K1 + K2 F(Q)^{K3}$$

- The K1, K2 and K3 in above equation is constant related to the character of medium. So the mass flow Q can be get through measuring the heating power rate P and difference of temperature TD. In actual application, there are two different methods, one is consistent current method and other one is consistent temperature method.

● Benefits

- Improves system efficiency
- Reduces system maintenance
- Reduces operating and energy costs
- Increases system understanding and operation
- Identifies changes in system performance
- Identifies non-productive air demand and leakage
- Identifies peak and average demand

● Key Features of thermal mass flow meter :

- Insertion type sensor.
- Independent of temperature and pressure change.
- Ultra wide 1:2500 turndown ratio, measurement range from 0.1 Nm/s to 250 Nm/s.
- 1.5" ultra wide viewing angle LCD capacitive touch.
- No moving parts, low pressure drop.
- Standard RS485 Modbus RTU interface and 4-20mA current/pulse output.

What's in the Box ?

- Each WAFS - 105 Flow Meter Unit comes with :




1. WAFS - 105 Flow Sensor
2. User Manual
3. 2X6 Pin M12 Connector with 2 meter cable
4. Calibration Certificate

- **Optional Accessories**

- The following accessories are available for WAFS - 105 Flow Meter. Talk to your local dealer for pricing and other accessories.



Y-type M12 connector for connecting multiple sensors simultaneously via RS485



Smart Data Acquisition and Monitoring Software

Product Specification

| Measuring Range | |
|-----------------------|-------------------------------------------------------------------------------------------------------|
| Flow Range | 0(0.1) ... 250 Nm/s |
| Accuracy | ±(1% reading + 0.3% Full Scale) |
| Sample Rate | Sample Rate |
| Reference Cond | 20°C, 1 bar(a) - ISO 1217 (Programmable) |
| Communication Output | |
| Analog (Standard) | 4...20 mA (Isolated) / Pulse Output |
| Digital (Standard) | RS485, MODBUS RTU Protocol |
| Connector | 2 x 5 - pin M12, Female |
| Power Supply | |
| Input | 18 to 30V / 5W |
| Display | |
| Display | 1.5" LCD with Capacitive Touch Panel |
| Operating Environment | |
| Op. Temp | -30 ... +70 °C |
| Medium Temp | -40 ... 150 °C |
| Op. Pressure | WAFS - 104 : 0...5.0 MPa (>1.6 MPa need Installation Device) WAFS - 105 : 1.6 MPa (Option:4.0 MPa) |
| Others | |
| Process Conn | G1/2" (ISO 228-1) |
| EMC | According to IEC 61326-1 |

Flow Range

| Pipe Size | | Flow Range (Nm ³ /h) | |
|-----------|--------|---------------------------------|----------------|
| DN | ID(mm) | Min Flow (cfm) | Max Flow (cfm) |
| 15 | 15 | 0.04 | 45 |
| 20 | 20 | 0.06 | 79 |
| 25 | 25 | 0.12 | 125 |
| 32 | 32 | 0.18 | 204 |
| 40 | 40 | 0.29 | 319 |
| 50 | 50 | 0.41 | 499 |
| 65 | 65 | 0.71 | 843 |
| 80 | 80 | 1.06 | 1278 |

Installation - Mechanical


To maintain the accuracy stated in the technical data, the sensor must be installed inline and fitted to tubes with the same diameter. Please consider that enough space exists at your site for an adequate installation as described in this manual.

WARNING!

- Incorrect installation can damage the sensor or cause it to work incorrectly.
- **Align the Sensor With Direction of Flow**
 - The flow meter is not bidirectional. When installing and using the flow meter, please pay attention to the direction of air flow and the alignment of the sensor.
 - The direction of flow is marked by 4 green arrows on the back of the sensor and underneath the sensor.


Correct Installation

The Sensor is aligned in the same direction as the gas flow.



Incorrect Installation


Note : Inaccurate measurement may occur if the sensor is installed incorrectly.



Installation - Electrical (Wiring)


- The flow sensor is equipped with two M12 connector plugs - "A" and "B". Cables are connected to the sensor through the M12 connector plugs.
- Do not screw the M12 connector using force. Otherwise, it may damage the connection pins.

Connector A (Modbus)



Pin 1_ Modbus RTU Data +
Pin 2_ Modbus RTU Data -
Pin 3_ Not Used
Pin 4_ +18~30v DC
Pin 5_ 0v DC

Connector B (Analogue)



Pin 1_ 4~20mA +
Pin 2_ 4~20mA -
Pin 3_ Pulse
Pin 4_ Pulse
Pin 5_ Not Used



1_ Connector A
2_ Connector B

Communication Settings

| MENU | SUB MENU 1 | SUB MENU 2 | SUB MENU 3 |
|----------|------------------------------------------|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Home | Flow, Consumption, Velocity, Temperature | | |
| Settings | Pipe Diameter | | |
| | Unit Setting | Flow unit | NM ³ /h, NM ³ /min, NM ³ /s, NI/min, NI/s, NCFM ,Kg/h, Kg/min, Kg/sec, SM ³ /hr, SM ³ /Min, SM ³ /sec, SI/min, SI/sec, SCHM |
| | | Velocity unit | NM/s, Nft/s, SM/sec, SFT/sec |
| | | Consumption unit | NM ³ , Nft ³ , Kg, SM ³ , SFT ³ |
| | Normalization | Normalized Temperature | |
| | | Normalized Pressure | |
| | RS 485 Setting | Baud Rate | 1200, 2400, 4800, 9600, 14400, 19200, 38400, 56000, 57600, 115200 |
| | | Parity | None, Odd, Even |
| | | Stop Bits | 1, 2 |
| | | Response Delay | |
| | | Device Address | |
| | Analog Setting | 4-20 MA Channel | Flow, Velocity, Temperature |
| | | 4-20 MA Scaling Low | |
| | | 4-20 MA Scaling High | |
| | | Pulse Output | |
| | System Setting | Brightness Setting | |
| | | Screen Timeout | |
| | | System Information | |
| | Advanced Setting | Gas Type | Air, Oxygen, Nitrogen, Hydrogen, Carbon dio. |
| | | Velocity Offset Ratio | |
| | | Velocity Filter Grad. | |
| | | Consumption | |
| | | Change Password | |
| | Password <input type="text"/> | | |

● **Default Modbus Settings**

Settings can be changed to suit system requirement

| Modbus Register | | | | |
|--------------------------|-----------|-------------|-------------|--------------|
| Holding Register Address | Data Type | Byte Length | Description | Read / Write |
| 0 | Float | 4 | Flow | Read |
| 2 | Float | 4 | Velocity | Read |
| 4 | Float | 8 | Consumption | Read |
| 8 | Float | 4 | Temperature | Read |

| Default Modbus RTU (RS 485) Settings | | | | | |
|--------------------------------------|-----------|---------------------------|---------------|----------------|---------------|
| Address | Baud Rate | Frame / Parity / Stop Bit | Response Time | Response Delay | Frame Spacing |
| 0 | 9600 | 8 / N / 1 | 1 Sec | 0 ms | 7 Character |

| Communication Configuration | | | | | |
|-----------------------------|---------|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|--------------|
| Holding Register | Address | Byte Length | Description | Default | Read / Write |
| 51 | 50 | 2 | Restart Device (write 1 to restart device) | | Write |
| 52 | 51 | 2 | Device Address (1 ~ 247) | 1 | Read / Write |
| 53 | 52 | 2 | Baud Rate 12 - 1200 bps 24 - 2400 bps 48 - 4800 bps 96 - 9600 bps 144 - 14400 bps 192 - 19200 bps 384 - 38400 bps 560 - 56000 bps 576 - 57600 bps 1152 - 115200 bps | 9600 | Read / Write |
| 54 | 53 | 2 | Parity 0 - None 1 - Odd 2 - Even | 0 | Read / Write |
| 55 | 54 | 2 | Stop Bit 1 - 1 bit 2 - 2 bit | 1 | Read / Write |
| 56 | 55 | 2 | Response Time Out 0 ~ 255 ms; 1 ms/ step; Value range : 0 ~ 255 | 0 | Read / Write |

Warranty

WiseAir Technologies provides a 12-month warranty for all Flow Meters. The warranty covers material and workmanship under the stated operating conditions from the date of delivery. Please report any issues immediately and within the warranty time.

If faults occur during the warranty period WiseAir Technologies will repair or replace the defective unit, without charge for repair labor and material costs but there is a charge for other services such as labor to remove or reinstall the instrument, transport and Warranty repairs do not extend the period warranty.

The following damage is excluded from this warranty:

- Improper use and non-adherence to the user manual.
- Use of unsuitable accessories. External influences (e.g. damage caused by vibration, damage during transportation, excess heat or moisture).

The warranty is cancelled when one of the following situations occurs:

- The user opens the measurement instrument without a direct request written in this manual. Repairs or modifications are undertaken by third parties or unauthorized persons. The serial number has been changed, damaged or removed.


Technical Support

Questions :

- I can't see all menu items
- The touch screen doesn't work
- Help! My sensor is in the wrong language.
- My sensor isn't reading correctly
- How do I clean the sensor?

I Can't See all Menu Items

- On some menus, you will need to scroll up and down to see all items. This is indicated by a scroll bar on the right side of the screen.



Calibration

The sensor is calibrated before delivery. The calibration date is printed on the certificate which is shipped with the sensor.

Flow meters require calibration to remain accurate. The frequency of calibration depends greatly on the level of contamination within your system. By using insertion style flow meters wherever possible, you can install and remove them without the need for shutting the system down, virtually eliminating any lost production time caused by periodic maintenance.

We recommend you calibrate the sensor every 2 years. The calibration is excluded from the product warranty. For more information, please contact **WiseAir Technologies**.

Need Help ?

Contact your local dealer. Alternatively, contact **WiseAir Technologies**

Call Us


Asia : **+91 90477 78715**
 Europe : **+45 36 99 04 22**

Email Us

Asia : **info@wiseair.asia**
 Europe : **info@wiseair.asia**


Help! My sensor is in wrong language

- If you need to change the language :
 - Step 1 - Unlock the Screen If the lock Screen symbol (🔒) is Present, press the symbol, hold and drag it to the right of the screen.
 - If the screen lock symbol is not present, skip this step.




● **The Touch Screen Doesn't Work**

- If the touch screen doesn't work:
 - Clean the screen
 - Make sure the Screen Lock is off.
- If the lock screen symbol is present, press the symbol, hold and drag it to the right of the screen.
 - Use your finger to touch the screen.
 - The touch screen does not work if you use finger nails or pens.
 - Try pressing harder, or softer



● **Go to System Settings**

- Scroll to the bottom of the setting screen.
- Press the "System Setting" Menu 2nd menu from bottom




● **Select desired language**

- Press the Arrow button (←) to save your selection and return to the previous screen


● **Go to the home page**

- Click on the Menu Icon on the top left of the screen, then click on the home icon 🏠





● **Go to Settings**

- Click on the Settings Icon ⚙️ on the top right of the home page.



● **Go to Language Settings**

- Scroll to the top of the system setting screen.
- Press the "Language Setting" Menu 2nd menu from top



● My Sensor Isn't Reading Correctly

● If your sensor is not reading the correct values, follow these steps.

1. Make sure the sensor is suitable for your system. Refer to the "Specifications" section for details.

2. Make sure the sensor is calibrated. Sensors should be calibrated every 2 years. Contact your local dealer or WiseAir Technologies for calibration.

3. Make sure the sensor tip is free of contamination.

4. Make sure the sensor is installed correctly. Refer to "Installation — Mechanical" for more information. The sensor should be installed vertically to the pipe, away from obstructions. Typical installation errors include:

- Installing sensor upside down or at an angle
- Installing sensor too close to bends and other obstructions
- Sensor tip is not in the center of the pipe, eg its too low or too high
- Installing sensor in the opposite direction to the gas flow
- Installing sensor directly on the outlet of the compressor
- Gas flow rate too low. Note: below 10 Nm/s the flow meter reading will be zero.

Please note: contamination on the sensor tip will affect calibration and accuracy of the sensor. Removal of the contamination may not fix the issue.

5. Make sure the sensor is wired correctly. Refer to "Installation — Electrical(Wiring)" section for more information.

6. Make sure the following sensors settings are correct:

- Inner Pipe diameter (not outer diameter)
- Unit of Measurement
- Gas Type
- Communication settings (RS485 or Analog) Refer to the "Setting Up the Flow Meter" and "Communication Settings" sections for more information.

7. If you have adjusted Normalization or Advance Settings, reset these to factory default.

● Normalization default setting: Temperature = 20°C and Pressure = 100 kPa.

8. Is your associated equipment compatible with the flow meter?

If you are still having problems, contact your local dealer or **WiseAir Technologies**.

How Do I Clean the Sensor?

- If you need to clean the sensor it is recommended to use a clean, dry cloth. For stubborn marks, use distilled water or isopropyl alcohol only.

Commissioning Report

About the Sensor

| | | | |
|-----------------------------|--|--------------------------|--|
| Part Number WAFS - 105 | | | |
| Serial Number | | | |
| Installed by | | Installed on (date) | |
| Calibration (Valid till) | | Warrenty (Valid till) | |

Installation

| Step | Task | Yes | NA | No | Comments | Sign |
|------|----------------------------------------------------------------------------------------------------------------|-----|----|----|-----------------------------------------------------------------|------|
| 1 | Flow meter installed in correct location and orientation? | | | | | |
| 2 | Flow meter installed away from obstructions | | | | | |
| 3 | Sensor tip aligned with center of pipe | | | | | |
| 4 | Sensor aligned with direction of gas flow | | | | | |
| 5 | Electrical wiring checked | | | | | |
| 6 | Sensor setting configured for : inner pipe diameter unit of measurement gas type and communication | | | | inner pipe Diameter : Gas Type : Unit of Measurement : | |
| 7 | Modbus settings ckecked | | | | | |
| 8 | Readings (flow, velocity, consumption & temperature) visible on display | | | | | |

Initials of WISEAIR Representative

Initials of Customer

Understand Compressed Air System Dynamics with Our Advanced Measurement Solutions

Measure - Manage - Save - Sustain

Our Network



ASIA REGIONAL OFFICE

WISEAIR TECHNOLOGIES INDIA LLP

#12 Sri Venkatalakshmi Nagar,
Singanallur, Coimbatore - 641 005. India
Mob : +91 - 90477 78715
Email : info@wiseair.asia

CONTACT US

North America : info.usa@wiseair.eu
Europe : info@wiseair.eu
Middle East : info.uae@wiseair.eu
South Asia : info@wiseair.in
South East Asia : info@wiseair.asia



For More Info
SCAN HERE

follow us @ [wiseair.asia](https://www.wiseair.asia)

